

# POLY-800 PLUS MDK

*Your POLY-800 has been enhanced to provide MIDI memory transfer capability (MDK).*

The Memory Transfer function enables external storage and manipulation of the POLY-800's program and sequencer data by a personal computer or the device connected to the MIDI IN and OUT jacks.

There are no controls on the POLY-800 for this purpose. The transfer request is made by the external computer through the POLY-800 MIDI IN jack. When the POLY-800 receives such a request, it "dumps" all data from its memory out the MIDI OUT port. (See MIDI IMPLEMENTATION section at the end of this manual for data formats and other information.)

Data included are:

1. MIDI Receive channel.
2. Sequencer note data.
3. Chord memory.
4. Program data.

When the POLY-800 gets a data transfer request, it takes about one second to send the data. During this period, all normal functions cease, including the display.

You can also download from an external computer to change the POLY-800 memory contents. The external computer issues a memory reload command to the POLY-800, followed by the memory data. During this time (normally approximately 1 second) all normal functions cease, including the display. If received data is erroneous, then the POLY-800 will send a data transfer error message out the MIDI OUT port.

*Details concerning this "POLY-800 Plus MDK" enhancement are as listed in the MIDI Implementation below.*

I purchased one of the last available MDK ROM sets from Korg for about \$50 in 1988. This upgrade gives the Poly-800 the ability to download its patch data via MIDI and not just through the built-in cassette interface. However, since it is a retrofit, one must use MIDI software that can make the request to the Poly-800, since it has no internal feature to say "Now I'm dumping to MIDI". Sorry for the quality of these scans -- my original documentation came in the form of bad photocopies.

# POLY-800 PLUS MDK MIDI IMPLEMENTATION

## 1. TRANSMITTED DATA

STATUS	SECOND	THIRD	DESCRIPTION
1000	000n	0kkk kkkk	0100 0000 NOTE OFF (FOOTNOTE 2)
1001	000n	0kkk kkkk	0100 0000 NOTE ON
1011	0000	0000 0001	0vVV v000 JOY STICK MOD. 1 (DCO) (FOOTNOTE 3)
		0000 0010	0vVV v000 JOY STICK MOD. 2 (VCF)
1011	000n	0111 1100	0000 0000 OMNI OFF
		0111 1101	0000 0000 OMNI ON MODE MESSAGE
		0111 1111	0000 0000 POLY ON
1100	0000	00pp pppp	PROGRAM CHANGE, # 11—# 88 (0—63)
1110	0000	0000 00bb	0bbb bbbb PITCH BENDER (0-40H—7FH) (FOOTNOTE 4)

### FOOTNOTE:

1. "n" will be "0" in case of the data from keyboard, and will be "1" in case of data from the sequencer.
2. Note number 0kkk kkkk=36-84.
3. JOY STICK MOD. Range has 4 bit resolution (0vVV v000).
4. PITCH BENDER has 7 bit resolution (0bbb bbb) only by THIRD BYTE.
5. MODE MESSAGES are transmitted together with sequencer START/STOP commands. When the sequencer is started, OMNI OFF and POLY ON will be transmitted to ch. 1 and ch. 2. When the sequencer is stopped, OMNI ON and POLY ON will be transmitted in the same way.

STATUS	DESCRIPTION
1111 1000	TIMING CLOCK
1111 1010	START (SEQUENCER START)
1111 1100	STOP (SEQUENCER STOP)

### NOTE:

TIMING CLOCK messages will be transmitted while the sequencer is working.

## 2. RECOGNIZED RECEIVE DATA 1

STATUS	SECOND	THIRD	DESCRIPTION
1000	nnnn	0--- ---	0xxx xxxx NOTE OFF VELOCITY will be ignored.
1001	nnnn	0--- ---	0vVV vVVV NOTE ON (vV vVV>0) VELOCITY will be ignored.
		0--- ---	0000 0000 NOTE OFF
1011	nnnn	0000 0001	0vVV vXXX MG 1 (DCO) 4 bit RESOLUTION Bits 0-2 will be ignored.
		0000 0010	0vVV vXXX MG 2 (VCF) 4 bit RESOLUTION Bits 0-2 will be ignored.
1011	nnnn	0111 1100	0000 0000 OMNI OFF
		0111 1101	0000 0000 OMNI ON (See FOOTNOTE 3)
1100	nnnn	0ppp pppp	PROGRAM CHANGE If the specified program number (ppp pppp) is larger than 63, it will be recognized as follows: SPECIFIED PROGRAM - 64=SELECTED PROGRAM EX. 70=6 64=0
1110	nnnn	0xxx xxxx	0bbb bbbb PITCH BENDER Third byte will be recognized, but second will be ignored.

### FOOTNOTE:

1. nnnn: 0-15. When the mode is OMNI ON, note data from all channels will be received. When the mode is OMNI OFF, only data of the channel designated by Parameter # 86 will be received. As to Mode Message, however, designated channel data only will be received even if the mode is OMNI ON.
2. Note Number (0kkk kkkk) is 36-84. If the data except above range were received, the data will be transposed to the same note on the nearest octave.
3. OMNI ON/OFF will be always recognized as the message with POLY ON. Single POLY ON or MONO ON message will be ignored.

### 3. RECOGNIZED RECEIVE DATA 2

STATUS	DESCRIPTION
1111 1000	TIMING CLOCK
1111 1010	SEQUENCER START
1111 1100	SEQUENCER STOP

#### FOOTNOTE

- **TIMING CLOCK** will be received only while the sequencer is working. (i.e., SEQ CLK (Parameter #88) is set to EXTERNAL (value-2)).

### 4. PANEL CONTROL

#### PARAMETER

**#86 RCV CH:** This value will be kept though the power is turned off. This Parameter is valid when the mode is OMNI OFF against messages except for MODE MESSAGE.

**#87 PROG CHANGE:** 0=DISABLE  
1=ENABLE  
This Parameter is valid only for receiving. Default value is "DISABLE".

**#88 SEQ CLK:** 1=Sequencer will be controlled by INTERNAL clock.  
2=Sequencer will be controlled by EXTERNAL clock from MIDI IN. Default value is "INTERNAL".

### 5. SYSTEM EXCLUSIVE MESSAGES (Transmission Data)

	STATUS	DATA	DESCRIPTION
RAM DATA	1111 0000	01000010	KORG ID
		00100001	FORMAT ID
		00000110	POLY-800 PLUS MDK ID
		0000++++	LSB 4 bit } RAM DATA
		0000++++	MSB 4 bit } 1-word
		...	
		0000ssss	LSB 4 bit } CHECK SUM
		0000ssss	MSB 4 bit } DATA
		11110111	EOX (END OF EXCLUSIVE)
	DATA ERROR MESSAGE	1111 0000	01000010
		00100001	FORMAT ID
		00000110	POLY-800 PLUS MDK ID
		00100000	DATA ERROR MESSAGE
		11110111	EOX

#### NOTE:

1. Data error message is sent if there is a check sum error during memory load. Error message: (F0<sub>h</sub>, 42<sub>h</sub>, 21<sub>h</sub>, 06<sub>h</sub>, 20<sub>h</sub>, F7<sub>h</sub>)
2. The request sent by the computer must be: F0<sub>h</sub>, 42<sub>h</sub>, 21<sub>h</sub>, 06<sub>h</sub>, 10<sub>h</sub>, F7<sub>h</sub> (where "h" means hexadecimal). Memory data is then output in the order: F0<sub>h</sub>, 42<sub>h</sub>, 21<sub>h</sub>, 06<sub>h</sub>, memory data, check sum, F7<sub>h</sub>.

**6. SYSTEM EXCLUSIVE MESSAGES**  
(Reception data)

	STATUS	DATA	DESCRIPTION
DUMP DATA	11110000	01000010	KORG ID
		00100001	FORMAT ID
		00000110	POLY-800 PLUS MDK ID
		0000****	LSB 4 bit } RAM DATA
		0000****	MSB 4 bit } 1-word
		0000ssss	LSB 4 bit } CHECK SUM
		0000ssss	MSB 4 bit } DATA
	11110111	EOX	
DATA DUMP REQUEST	11110000	01000010	KORG ID
		00100001	FORMAT ID
		00000110	POLY-800 PLUS MDK ID
		00010000	DATA REQUEST
		11110111	EOX

**NOTE:**

1. POLY-800 begins RAM data dump about 300msec after it receives the final F7H in the RAM data request above.
2. Least significant 8 bits of  $\frac{100}{n-1}$  (One word of RAM data)n are used for check sum.
3. Send data to POLY-800 MIDI IN in the order: F0H, 42H, 21H, 06H, memory data, check sum, F7H, Internal.

**7. RAM DATA CHART**

DATA	RELATIVE ADDRESS	BYTES
MIDI CH DATA	0 0 0 0 ..	1
SEQUENCER DATA	0 0 0 1 ..	256
UNDEFINED	0 1 0 1 ..	1
CHORD MEMORY	0 1 0 2 ..	8
UNDEFINED	0 1 0 A ..	22
PROGRAM DATA	0 1 2 0 ..	1345

**NOTE:**

1. SEQ DATA is as shown below.

SYMBOL	DATA	NOTE
	0 0H	Fine
	0 1H	Rest
	0 2H	Tie
	1 k <sub>1</sub>	MSB=0: Notes remain for that timing. MSB=1: Block end for that timing.
	0 k <sub>2</sub>	
	1 k <sub>2</sub>	

**EXAMPLE:**



DATA: B4H, 02H, B5H, 02H, 01H, 01H, B7H, B9H, 34H, 37H, BC<sub>H</sub>, 02H, 02H, 02H, 02H, 02H, 01H, 01H, 00H

**2. CHORD MEMORY**

0 k<sub>n</sub>k<sub>n</sub>k<sub>n</sub>k<sub>n</sub>k<sub>n</sub>k<sub>n</sub>k<sub>n</sub>k<sub>n</sub>: KEY DATA  
0 0 0 0 0 0 0 0: END

3. Important: POLY-800 does not use undefined data except for check sum.

Program Parameter per ONE note

Byte	bit	7	6	5	4	3	2	1	0
1		DCO 2 WAVEFORM		DCO 1 WAVEFORM		DCO 2 OCTAVE		DCO 1 OCTAVE	
2		DCO 2 FEET ON/OFF				DCO 1 FEET ON/OFF			
3		CHORUS ON/OFF	DCO 2 ON/OFF	UNDEFINED			DCO 2 DETUNE		
4		NOISE LEVEL				DCO 2 INTERVAL			
5	*	DCO 1 LEVEL	VCF EG POLARITY		VCF EG INT				
6		UNDEFINED		DCO 2 LEVEL				*	
7		VCF TRIGMODE	VCF CUT OFF						
8		MG DELAY				MG FREO			
9		MG VCF INT				MG DCO INT			
10	*	DEG 1 DECAY				DEG 1 ATTACK			
11	*	DEG 1 BREAK P						*	
12	*	DEG 1 SUSTAIN				DEG 1 SLOPE			
13	*	DEG 1 RELEASE						*	
14		DEG 2 DECAY				DEG 2 ATTACK			
15	*	DEG 2 SLOPE				DEG 2 BREAK P			
16	*	DEG 2 SUSTAIN						*	
17	*	DEG 3 ATTACK				DEG 2 RELEASE			
18	*	DEG 3 DECAY						*	
19		DEG 3 SLOPE				DEG 3 BREAK P			
20	*	DEG 3 RELEASE				DEG 3 SUSTAIN			
21		VCF KBD TRACK		VCF RESONANCE				*	

PRAMETER WITH \* EXCEEDS BYTE UNIT.  
NO SPACE BETWEEN NOTES