

## Elektron SID STATION — MIDI Implementation Chart

Function		Transmitted	Recognised	Remarks
BASIC CHANNEL	Default: Changed:	1 1–16	1 1–16	memorized Tx & Rx channel are the same
MODE	Default: Messages: Altered:	X X *****	Mode 3, 4 X X	Can only switch between mono ('SINGLE') & poly modes via front panel.
NOTE NUMBER	True Voice:	X *****	0–127 12–106	For untransposed osc's. Below note 12, osc is transposed up one 8ve; above note 106, pitch stays constant.
VELOCITY	Note ON: Note OFF:	X X	O X	Routeable to LFO params.
AFTERTOUCH	Key's: Ch's:	X X	X O	Routeable to LFO params.
PITCH BEND		X	O	Routeable to Osc pitch & LFO params.
CONTROL CHANGE	1  16, 17, 18, 19 20, 21, 22, 23  24–63, 70–95, 100–117	X  O X X	O  O O O	Mod wheel. Routeable to Osc vibrato, PWM, filter cut-off, and LFO params. Direct controller knobs 1–4 Routeable to LFO params. (i.e. LFO depth, speed, S&H rate, interlace rate) Voice parameters real-time control (refer to Owner's Manual for details).
PROGRAM CHANGE	True#:	X *****	O P0–P99	
SYSTEM EXCLUSIVE		O	O	For clear all patches, patch dump, skip patch, direct programming of voice parameters (refer to Owner's Manual for details). Elektron Manufacturer ID: 00 20 3C H SID Station Device ID: 01 H
SYSTEM COMMON	Song Pos: Song Sel: Tune:	X X X	X X X	
SYSTEM REAL TIME	Clock: Commands:	X X	O X	For clocking patch parameter updates
AUX MESSAGES	All Sound Off: Reset Controllers: Local ON/OFF: All Notes OFF: Active Sensing: System Reset:	X X X X X X	X X X O X X	

Mode 1: OMNI ON, POLY  
Mode 3: OMNI OFF, POLY

Mode 2: OMNI ON, MONO  
Mode 4: OMNI OFF, MONO

O: YES  
X: NO