

There are always 3 pattern banks - but these numbers are only used internally by P3.
 The 16 patterns for each track in each pattern bank are divided up among the other user banks
 if there are 6 or 12 user banks configured.

3 Banks

User Bank

	1	2	3
Pattern 1	1, 1	2, 1	3, 1
2	1, 2	2, 2	3, 2
3	1, 3	2, 3	3, 3
4	1, 4	2, 4	3, 4
5	1, 5	2, 5	3, 5
6	1, 6	2, 6	3, 6
7	1, 7	2, 7	3, 7
8	1, 8	2, 8	3, 8
9	1, 9	2, 9	3, 9
10	1, 10	2, 10	3, 10
11	1, 11	2, 11	3, 11
12	1, 12	2, 12	3, 12
13	1, 13	2, 13	3, 13
14	1, 14	2, 14	3, 14
15	1, 15	2, 15	3, 15
16	1, 16	2, 16	3, 16

6 banks

User Bank

	1	2	3	4	5	6
Pattern 1	1, 1	2, 1	3, 1	1, 9	2, 9	3, 9
2	1, 2	2, 2	3, 2	1, 10	2, 10	3, 10
3	1, 3	2, 3	3, 3	1, 11	2, 11	3, 11
4	1, 4	2, 4	3, 4	1, 12	2, 12	3, 12
5	1, 5	2, 5	3, 5	1, 13	2, 13	3, 13
6	1, 6	2, 6	3, 6	1, 14	2, 14	3, 14
7	1, 7	2, 7	3, 7	1, 15	2, 15	3, 15
8	1, 8	2, 8	3, 8	1, 16	2, 16	3, 16

Number pairs show
pattern bank, pattern number

12 banks

User Bank

	1	2	3	4	5	6	7	8	9	10	11	12
Pattern 1	1, 1	2, 1	3, 1	1, 5	2, 5	3, 5	1, 9	2, 9	3, 9	1, 13	2, 13	3, 13
2	1, 2	2, 2	3, 2	1, 6	2, 6	3, 6	1, 10	2, 10	3, 10	1, 14	2, 14	3, 14
3	1, 3	2, 3	3, 3	1, 7	2, 7	3, 7	1, 11	2, 11	3, 11	1, 15	2, 15	3, 15
4	1, 4	2, 4	3, 4	1, 8	2, 8	3, 8	1, 12	2, 12	3, 12	1, 16	2, 16	3, 16